# User Guide 01B

Product detail

i roddot dotaii	
Product name	6-button wireless mouse
Part no	ET-MR5M2509-1
Wireless connection	2.4GHz
Resolution/ DPI	Switchable 800/1200/1600/2000/2400
Chipset	MA38JW-3+3065
Operational distance	Approx. 10m
Scanning Speed	30ips
Case material	ABS
Key Operation Force	55g±7g
Button lifetime	3 million
Dimension	4.1*2.8*1.5 inches 104*71*38 millimeters
Weight	2.5 ounces / 70 grams

### **Functions**



This mouse will automatically

hibernate and shut down to conserve power after eight minutes without use. Press any button to wake the mouse. Receiver features

EN English Version

The nano receiver can be placed in the bottom of the mouse for storage when not in use.

Located on the mouse, open the battery cover to There is also a storage area for the nano receiver under the battery door.

# DPI adjustment function

these two buttons are

forward and backward.

This mouse has 800/1200/1600/2000/2400 adjustable DPI. To change DPI settings press down the button below the Scroll wheel. DPI adjustment process: 800 DPI: press down the button until DPI light flashes once

1200 DPI(default): press down the button until DPI light flashes twice 1600 DPI; press down the button until DPI light flashes three times

2000 DPI: press down the button until DPI light flashes four times 2400 DPI: press down the button until DPI light flashes five times

Note: if the mouse lost connet with the receiver, customer can reconnect them by press the middle button and the right button simultaneously for about three seconds

**EN** English Version

#### User Guide 01B

#### Product detail

Product name	Wireless keyboard
Part no	ET-KR8103-1
Wireless connection	2.4GHz
Number of keys	104
Button lifetime	10 million
LED indicator	Caps Lock / NumLock(low battery)
Case material	ABS
Dimension	17.5 x 5.1 x 1 inches 445 x 131 x 25 millimeters
Weight	14.2 ounces / 401 grams

#### Functions



[FN]+[F1~F12] keys

[FN]+[F1] Media player

FII [FN]+[F7] Play/ Pause ■ [FN]+[F8] Stop

[FN]+[F2] Volume down

[FN]+[F3] Volume up

(FN]+[F4] Mute

[FN]+[F5] Previous track

[FN]+[F11] My computer

[FN]+[F6] Next track

[FN]+[F12] My favorite

(FN)+(F9) Home

[FN]+[F10] Email

2 Windows key: Press to launch the Windows start menu.

Menu/ application key: Press to launch a context menu. Similar to using the right-mouse button.

"ESC" + "K": reconnect keyboard and receiver while lose connect or no battery

EN English Version

#### User Guide 01B

# Product detail

Product name	MP1 Gaming Mousepad
Part no	ET-MP1
Front	Silk
Back	Foam Rubber
Edge	Stitched Edges in Black
Product Dimension	330 x 260 x 3mm / 12.99 x 10.24 x 0.15in
Product Weight	130g / 4.6oz

# **Functions**



Foam Rubber Bottom



Water Proof

# Package contents

Wirelss keyboard
6-button wireless mouse.
Nano receiver
Mousepad
User Guide

All product specifications and information on this user manual is for reference only, the product specifications are subject to change without notice.

All trademarks are properties of their respective owners.

To assure product safety, follow the precautions in the instruction manual.

x 1

EN English Version

Thank you for your recent purchase. We appreciate your business and want to make sure you have a positive experience.

If you are happy with your purchase, please take a moment to share your experience with others via an Amazon.com review.

If there are any problems with any of our products please contact us via the support form at www.eagletec.com or email us at cs@eagletec.com.

MANN MANN NAMES A F

**EagleTec**®